



### DIP switch settings

DIP	ON ▽	OFF ▲
1	Add-on microphone	Original microphone
2	Set to OFF ▲	
3	Selection for system version	
4		
5	Selection for screen size	
6		
7	Set to OFF ▲	
8	Set to ON ▽	

System ver.	3	4
Default	OFF ▲	OFF ▲
Option 2	OFF ▲	ON ▽
Option 3	ON ▽	ON ▽

Screen size	5	6
7 / 8.4 inch (800*480)	OFF ▲	OFF ▲
12.3 inch	OFF ▲	ON ▽
8.4 inch (960*540)	ON ▽	ON ▽

Switch:

